



**BARO SENSOR SUPPLEMENT**

**2015 AND UP FORD MUSTANG/FISO**



WHIPPLE SUPERCHARGERS  
3292 NORTH WEBER AVE  
FRESNO, CA 93722  
TEL 559.442.1261  
FAX 559.442.4153

[www.whipplesuperchargers.com](http://www.whipplesuperchargers.com)

*A color PDF of this manual is available, email  
[tech@whipplesuperchargers.com](mailto:tech@whipplesuperchargers.com) for a copy*

**PREMIUM FUEL ONLY (91 OCTANE OR BETTER ALWAYS) RON+MON/2**

## INSTRUCTIONS

1. Locate the driver side IMRC connector (yellow/orange, green/violet, yellow/green). Connect the supplied pigtail to this and route down the driver side of valve cover/supercharger towards airbox. Secure with zip-ties to heater hose.
2. Using a 3/8" drill bit, drill a hole for the baro/MAP sensor in the lower Whipple airbox.
3. Using the supplied 6mm SHCS, 6mm AN washer and 6mm nyloc nut, install to the airbox. This will now be used for barometric pressure reading.



**TMAP**  
Manifold Absolute Pressure  
Temperature Sensor

